

Installation Guidelines for WAS8040 (American Standard 8040 Bath Accessories)

INSTALLATION:

- Create 1 ¼" holes at the appropriate locations.
- Clear any debris from within the wall hollow that could interfere with the installation of the patented WingIt Fastening System.
- Measure the thickness of the wall substrate and back the ¼-20 screw out of the WingIt the same amount.
- Remove the inside tape liner and install the WingIt(s) into the wall. Hold securely for a moment to allow tape to bond.
- Hit the head of the screw with a hammer.
- Tighten by hand, then with a screwdriver.
- Mount the fixture base to the WingIt using the supplied screws.
- Assemble the fixture.

WingIts maintain their coned shape within the wall hollow to maximize load capacities and insure years of use.

THE ULTIMATE FASTENING SYSTEM – *WingIts* will maintain nearly 100% of their structural integrity – no matter which direction the loading occurs, or how often.

Use a minimum of Two WingIts per mounted accessory. Items such as Baby Changing Tables, Closet Brackets, Towel Racks, etc... require WingIts to be installed in every mounting location to insure warrantee on the WingIts Fastening System.

Never Install WingIts into Wet or Deteriorating Walls.

Notes: Standard WingIts work in substrates up to 1 ½" thick.