



9. Measure out the thickness of the wall on the *WingIt™* and back off the nut accordingly. For example, picture #8 shows a wall thickness of 3/4" (19mm). In this example you would back off the nut 3/4" (19mm) on the *WingIt™*. This will allow adequate clearance.



10. Attach *WingIt™*s to Grab Bar. FOR WINGIT GRAB BARS USE 2 SCREWS PER FLANGE.



11. Peel off **WATERPROOF** tape liner. Wall surface must be cleaned.



12. Insert Grab Bar into 1-1/4" (30mm) holes – Hold down firmly allowing the tape to adhere to tile wall.



13. Remove the Grab Bar, and the front of the *WingIt*s are visible.



Picture Above Shows the *WingIt™* as it would look inserted into the wall.



14. Verify the length of the nut from the *WingIt™* faceplate is correct (step 8) – Then hit the *WingIt™* firmly with a rubber hammer.



Picture on Left shows the *WingIt™* after it is pushed through the wall. The wings are automatically actuated as they spring out.

DO NOT OVERTIGHTEN
Once the nut is tightened, Add a second nut to insure the *WingIt™* will never loosen.



15. Pull on the bolt and tighten the nut by hand.

- ▲ Use a Nutdriver (screwdriver with a 7/16" (11mm) socket), this will insure that you do not overtighten.
- ▲ When using a cordless drill make sure to use a clutch setting.
- ▲ When using a 7/16" (11mm) wrench tighten firmly until you feel the *WingIt™* is secure



Picture Above Shows the inside of the wall after the *WingIt™* has been installed.



For Technical Support and Installation Advice:

Please call Toll Free (877) 8WINGITS or (877) 894-6448

Fax (908) 369-8922